


Guidance for setting WIFI in Chrome

1. Get wifi info from device:



2. PC connect printer's WIFI 【 Printer-AP】



3. Open chrome in PC, type in printer's IP:

A screenshot of a login page. It has a title '登录' (Login) and a subtitle 'http://192.168.0.1'. Below this, there is a text input field for the username, which contains 'admin'. To the right of the input field, there is a label '用户名' (Username). Below the input field, there is a text input field for the password, which is empty. To the right of the input field, there is a label '密码' (Password). At the bottom right, there are two buttons: '登录' (Login) and '取消' (Cancel).

User name: admin

Password: admin

4. Now you can set the wifi parameter from PC chrome.

A screenshot of a web interface for a printer. On the left, there is a sidebar with a menu. The menu items are: '系统信息' (System Information), '模式设置' (Mode Settings), 'STA设置' (STA Settings), 'AP设置' (AP Settings), '其它设置' (Other Settings), '账号管理' (Account Management), '软件升级' (Software Upgrade), '重启' (Restart), and '恢复' (Recovery). The '系统信息' (System Information) item is selected. The main content area shows the following information:

设备序列号	HF-LPT230
软件版本号	4.13.26 (2020-03-20 11:00 2M)
WiFi工作模式	AP
AP模式	
SSID	HF-LPT230
IP地址	10.10.100.254
MAC地址	EC:FD:F8:C0:B8:4A
STA模式	
路由器SSID	
信号强度	
IP地址	
MAC地址	

At the bottom right, there is a language selector with '中文' and 'English'. At the bottom center, there is a version number 'Web Ver:1.0.14'.